

Worldwide distributor: Audioscope 2k S.r.l.

Q-A232 Multiviewer. 2RU size Unit. 32xSD-HD-3G Ins on 2xDVI-I Outs.

- Up to 8 x Video Ip boards for max 32 x Video Ins: SD/HD/3G/CVBS auto-sensing; other video input connector types depending on the rear connector panel fitted. (See removable input connector backpanels).
- 6 x Keys to navigate the on screen menu, 10 x Keys to store / recall video presets.
- Each one Video Ip board holds 4 x Video Inputs; SD/HD/3G, CVBS, RGB/YUV, 4xDVI-I, 2xVGA @1080P.
- Two Video Outputs; DVI-I; resolutions up to HD 1080p60, 16:9 (1920 x 1080).
- Control via LAN with browser software operating on a PC.
- Single PSU installed. External redundant PSU upon request. Fan assisted ventilation with Failure alarm LED.




- Power ON/OFF switch. It is located behind the front panel, on the right side.
- USB-2 socket for keyboard.
- LEDs indicating the presence of the DC power of both the internal and external (if connected) power supplies.
- LED indicating abnormal unit condition.
- 6 x navigation keys for the on-screen menu. 10 x preset buttons to store/recall video configurations presets.

Q-A232 Multiviewer Rear Panel.



- Power line socket. External +24V. PSU connector.
- RJ45 connector for Ethernet (LAN) for browser, NTP clock update and/or remote panel control.
- USB connector. RS232/RS422 port for UMD tally via TSL, Image Video or other protocols.
- LTC / Genlock BNC Connectors.
- Two Video Outs; DVI-I; resolutions up to HD 1080p60, 16:9 (1920 x 1080). (Both Analogue and Digital).
- Additional GPI/Os 26-pole Sub-D connector. 25 way 'D' male connector for audio monitoring out.

Removable input connector backpanels: For Q-Frame, Q-Ext, Q-A232, Q-MVS, Q-MVD units.





Rear code: Q-CONN-06: 4 x SD-HD-3G & CVBS +4 x SD-HD-3G Loop trough + GPI/O. Loop though is for SD-HD-3G. (Not for CVBS).